

FOCUS

SINGLE BARREL SHOTGUN INSTRUCTION MANUAL

READ THE INSTRUCTIONS AND WARNINGS IN THIS MANUAL CAREFULLY BEFORE USING THIS FIREARM

SAFETY FIRST

Please do not use your shotgun before reading safety rules and this manual. Observe these rules of safe gun handling.

- 1. Always keep the muzzle pointed in a safe direction. Watch the muzzle at all time, never point a gun. accidentally or intentionally, at any person or anything you do not intend to shoot. Identify the target before shooting; do not shoot at sounds.
- 2. Always treat a gun as if it is loaded it may be!
- 3. Keep your finger off the trigger while operating the action and at all other times until you are ready to shoot.
- 4. Keep the safety "on" or in the "safe" position at all times until you are ready to fire. Do not rely on your gun's safety, the safety on any gun is a mechanical device and is not intended as a substitute for common sense or safe gun handling.
- 5. Learn how your gun functions and handles. If you do not thoroughly understand the proper use and care of your gun, seek the advice of someone who is knowledgeable.
- 6. Do not alter or modify any part of the firearm.
- 7. Store guns unloaded, separate from any ammunition, and out of the reach of children.
- 8. Be sure the barrel is clear of any obstructions before loading. Make it a habit to check the barrel every time before loading.
- 9. Be sure you have and use the proper ammunition. A 20-gauge shell will enter a 12-gauge chamber far enough so that a 12-gauge shell can be loaded behind it. Also, a 3-inch shell may fit into a 2-inch chamber, but the crimp at the mouth of the shell will unfold into the forcing cone. If either of these things occur and you fire the gun, the gun will explode, damaging the gun and possibly causing serious injury or death to you and those around you.
- 10. Wear protective shooting glasses and adequate ear protection when shooting.
- 11. Never climb or jump over anything, such as a tree, fence, or ditch, with a loaded gun. Put safety ON. Open the barrel on barrel break shotguns, remove the shells/discharge the chamber on pump and semi-auto shotguns and hand the gun to someone else or place it on the ground on the other side of the obstacle before crossing it yourself. Do not lean a gun against a tree or other object; it could fall and possibly discharge.
- 12. Do not shoot at a hard surface or at water. Bullet and shot can ricochet or bounce off and travel in unpredictable directions with great velocity.
- 13. Never transport a loaded gun. DO NOT place a loaded gun into a vehicle. The gun should be unloaded and placed into a case when not in use.
- 14. Never drink alcoholic beverages before or during shooting.
- 15. Never try to repair the shotgun on your own if you are not educated or expert of. This may cause un-willed damage to your gun which may seriously injure you or someone around you.



WARNING: Read and understand all instructions and warnings in this manual BEFORE using this shotgun. It is important to learn the parts of your shotgun and their functions before using this firearm.

BREAK OPEN LEVER

The Break Open Lever is located in front of the trigger guard and controls the locking of the breech of the barrel to the receiver. To open the gun, pull the Break Open Lever fully rearward and ease down the barrel.

NOTE: Pulling the Break Open Lever partially rearward will not disengage the locking of the breech. The Break Open Lever may appear to be pulled back fully rearward, but is not. Pulling the Break Open Lever slightly further will fully disengage the locking of the breech.

SAFETY BUTTON

The safety button is located at the rear of the trigger guard and must be manually moved to the desired position by the shooter.

To put the safety in the "Safe" or "On" position, the safety button must be pushed from the left side so that it moves all the way to the right. The button must always be pushed fully to the right until it moves no further to be in the "Safe" or "On" position.

The safety button is designed to function only as described above and should not be reversed. DO NOT attempt to remove or reverse the safety button. Doing so may result in an unsafe condition which can cause serious injury or death.

WARNING: Do not rely solely on your gun's safety. Treat every gun as if it is loaded and ready to fire. The safety is a mechanical devise and is not intended to serve as a substitute for common sense or safe gun handling. Always keep the muzzle pointed in a safe direction.

EXTRACTOR

This gun is equipped with an extractor. Once the Break Open Lever is pulled fully rearward and the action is opened, the extractor will partially elevate both fired and unfired shells in the chamber for easy removal by hand.

FIRING

WARNING: Read and understand all instructions and warnings in this manual BEFORE using this shotgun. It is important to learn the parts of your shotgun and their functions before using this firearm. Be sure of your target and what is beyond before firing.

After inserting the shot shell into the chamber, close and lock the breech. Your shotgun is ready to fire. Disengage the safety by pushing the safety button to the "Fire" or "Off" position, the safety button must be pushed from the right side so that it moves all the way to the left. The button must always be pushed fully to the left until it moves no further to be in the Fire "or "Off" position. This will display a red band marking around the safety as an indicator that the safety is in the "Fire" or "Off" position.



Pull the bolt handle to open the gun,as shown (Figure 1)



Break your gun gun for loading as shown (Figure 2)




After loading the gun, close the barrel to be ready fire, as shown (Figure 3)




Push the safety button for safety mode. When the shotgun was in this mode, you can not see "red alert" colour on safety button. important: please keep the shotgun in safety mode everytime while you are not shooting.

SINGLE BARREL GENERAL ASSEMBLY



PARTS LIST

I	1)	STOCK
I	2)	RECIEVER
I	3)	BARREL
I	4)	FORE-END
I	5)	TRIGGER GROUP
I	6)	BOLT HANDLE (TAKE DOWN LEVER)
I	7)	BOLT HANDLE SPRING
I	8)	RECIEVER MAIN SCREW
I	9)	RECIEVER MAIN SCREW
I	10)	FIRING PIN
I	11)	FIRING PIN SPRING
I	12)	FIRING PIN BUSHING
I	13)	EJECTOR
I	14)	EJECTOR EXTENTION
I	15)	EJECTOR SEAR
I	16)	EJECTOR SEAR PIN
I	17)	BUTT PLATE (RECOIL PAD)
I	18)	STOCK SCREW
I	19)	WASHER
I	20)	SLING SWIVEL
I	21)	FORE-END SLING SWIVEL
I	22)	FRONT SIGHT
Į	23)	BARREL SLING SWIVEL
	24)	BUTT PLATE SCREW
Į	25)	TRIGGER GROUP PINS



- 5-A) TRIGGER GROUP
- 5-B) SAFETY BUTTON
- 5-C) TRIGGER GROUP PIN
- 5-D) PLUNGER SAFETY_
- 5-E) PLUNGER SAFETY SPRING
- 5-F) TRIGGER CONNECTOR SPRING
- 5-G) TRIGGER CONNECTOR
- 5-H) TRIGGER
- 5-I) HAMMER
- 5-K) HAMMER PIN
- 5-L) HAMMER SPRING



SERVICE AGREEMENT AND LIMITED WARRANTY



BATMAZ GROUP ARMS agrees to service its products free of charge for defects in materials and workmanship in accordance

with the service agreement listed below. The obligation of Batmaz Group Arms under this agreement is limited to the repair or replacement of unserviceable parts and does not cover any incidental or consequential damages. Other than the express warranty contained herein Batmaz Group Arms makes no warranties, express or implied.

Batmaz Group Arms will repair or replace any unserviceable part(s) for one (1) year from date of purchase and further will supply free parts (Wood not included) for an additional one (1) years in accordance with the above warranty statement provided your firearm had not been altered, abused, willfully damaged, or damaged by overpressure ammunition. This agreement is not transferable; its benefits apply only to the original purchaser.

To obtain free service during the time this agreement is in effect, make sure your firearm is unloaded, and send it to Batmaz Group Arms.

This agreement and the warranties contained herein are void if your registration card is not received with a copy of your sales slip within 30 days from date of purchase



SHIPPING

When returning your gun for service, please take care in packing. Disassemble your gun, wrap in paper or other protective media and place gun in the original box. (THIS BOX WILL PROTECT THE GUN BUT IS NOT DESIGNED FOR SHIPPING). Warp box in a cardboard box approved for interstate shipping. Batmaz Group Arms is not responsible for damage incurred during shipping

WARRANTY CARD

PURCHASER						
Street						
City		State	Zip			
Phone						
Purchase Date						
PRODUCT: Model	Gauge	Serial#				
SIGNATURE						

Please sign and return this card to validate warranty



NOTICE:

This firearm was carefully inspected and test fired before shipment from our factory. However, we cannot control the handling of these firearms once they leave our factory. For your own protection; please examine the gun carefully at the time of purchase. The mechanism has been correctly designed, fitted and tested. However, any mechanical device can fail and no mechanism can prevent accidents caused by careless or thoughtless handling. Never premit the muzzle to point at anything which you do not wish to shoot. Always check to make sure that the gun is unloaded before handling. Be sure of your backstop or direction of fire before shooting.

> Beytepe Mahallesi Şehit İdris Ulu Caddesi No:1/A Beyşehir, Konya, TÜRKİYE